



125 Ricefield Lane, Hauppauge, New York 11788
Phone: 631 864 3699 Toll Free: 800 527 9156
Fax: 631 864 2631 Email: sales@januselevator.com
www.electronicmicrosystems.com www.januselevator.com



Power Pack Instructions – MG3

(PN#: MG3POWPK)

1. Connect the 24VDC transformer to the “P4” (PWR) power connector on the MG3 board.
Note: The Power connector of the MG3 board is polarity sensitive. The positive wire is labeled. It will not work if it is connected with reverse polarity
2. Connect the 24VDC transformer to 110VAC outlet.
3. Connect Battery Lead connector to the “P5” (BATTERY 8.4V NiMH) connector of MG3 circuit board.
4. Connect Battery Lead to the 8.4 Volt NiMH rechargeable battery.
5. Test the MG3 phone by pressing the Call button. The phone should turn “ON”.
Disconnect the transformer and make sure that the MG3 phone remains “ON”.
Press and hold the Call button for 3 seconds to turn the MG3 phone “OFF”.
Reconnect the 24VDC transformer to the MG3 phone.